

# Joie™ signature

---

finiti™













stroller



GB Instruction Manual










# IMPORTANT - READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.












## Stroller Assembly


























Stroller Operation
































**Accessories (May not be included in purchase)**  
 Accessories may be sold separately or may not be available depending on region.









Detach & Assemble Soft Goods



Care and Maintenance



## **GB** Welcome to Joie™

Congratulations on becoming part of the Joie family! We are so excited to be part of your journey with your little one. While traveling with the Joie Finiti™, you are using a high quality, fully certified stroller, complies with Australian Trade Practices Act 1974 Consumer Protection Notice No 8 of 2007 and AS 2088:2022. This product is suitable for children up to 22kg or 4 years whichever comes first. Please carefully read this manual and follow each step to ensure a comfortable ride and best protection for your child.

**IMPORTANT - READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.**

Visit us at [joiebaby.com](http://joiebaby.com) to download manuals and see more exciting Joie products!

For warranty information, please visit our website at [joiebaby.com](http://joiebaby.com)

## **Contents**

Figures	1-15
WARNING	21
<b>Stroller Assembly</b>	<b>25</b>
Open Stroller	25
Assemble & Detach Front Wheel	25
Assemble & Detach Rear Wheel	25
Assemble Canopy	25
Assemble & Detach Cupholder	25

<b>Stroller Operation</b>	<b>26</b>
Adjust Backrest	26
Use Buckle	26
Use Shoulder & Waist Harnesses	27
Use Armbar	27
Adjust Calf Support	27
Use Front Swivel Lock	28
Use Brake	28
Use Canopy	28
Adjust Handle	28
Switch Seat	28
Use Storage Bag	28
Use Tether Strap	29
Fold Stroller	29
Use Accessories	29
<b>Detach &amp; Assemble Soft Goods</b>	<b>31</b>
<b>Cleaning and Maintenance</b>	<b>32</b>

## **Emergency**

In case of emergency or accident, it is most important to have your child taken care of with first aid and medical treatment immediately.

# Product Information


Read all the instructions in this manual before using this product. If you have any further questions, please consult the retailer. Some features may vary depending on model.

<b>Product</b>	Finiti Stroller
<b>Suitable for</b>	This product is suitable for children up to 22kg or 4 years whichever comes first
<b>Materials</b>	Plastics, metal, fabrics
<b>Patent No.</b>	Patents pending
<b>Made in</b>	China
<b>Brand Name</b>	Joie
<b>Website</b>	<a href="http://www.joiebaby.com">www.joiebaby.com</a>
<b>Manufacturer</b>	Allison Baby UK Ltd.

# Parts List

Make sure all parts are available before assembly. If any part is missing, please contact local retailer. No tools are required for assembly.


- |                  |                     |
|------------------|---------------------|
| 1 Stroller Frame | 12 Storage Basket   |
| 2 Canopy         | 13 Shoulder Harness |
| 3 Front Wheel    | 14 Cupholder        |
| 4 Rear Wheel     | 15 Handle           |
| 5 Cupholder      | 16 Canopy Window    |
| 6 Seat Pad       | 17 Recline Handle   |
| 7 Armbar         | 18 Tether Strap     |
| 8 Calf Support   | 19 Storage Bag A    |
| 9 Footrest       | 20 Storage Bag B    |
| 10 Front Wheel   | 21 Storage Latch    |
| 11 Swivel Lock   | 22 Brake Lever      |
|                  | 23 Rear Wheel       |



# Accessories

(May not be included)

- |                  |          |
|------------------|----------|
| 1 Adapter        | 2 Insert |
| 3 Rain Cover     |          |
| 4 Storage Pocket |          |
| 5 Carrying Belt  |          |



Accessories may be sold separately or may not be available depending on region.

## WARNING

- ! FOLLOW THE MANUFACTURER'S INSTRUCTIONS.
- ! PUT ON ALL THE BRAKES WHENEVER YOU PARK THE PRAM/STROLLER.
- ! DO NOT LEAVE CHILDREN UNATTENDED.
- ! DO NOT CARRY EXTRA CHILDREN OR BAGS ON THIS PRAM/STROLLER.
- ! **MAKE SURE CHILDREN ARE CLEAR OF ANY MOVING PARTS IF YOU ADJUST THE PRAM/STROLLER, OTHERWISE THEY MAY BE INJURED.**
- ! THE BRAKES MUST ALWAYS BE APPLIED WHEN THE PRAM/STROLLER IS NOT MOVING.
- ! ALWAYS KEEP CHILD IN VIEW WHILE IN PRAM/STROLLER.
- ! SECURE THE CHILD IN THE HARNESS AT ALL TIMES.
- ! TO AVOID SERIOUS INJURY FROM FALLING OR SLIDING OUT, ALWAYS USE SEAT BELT.
- ! USE THIS STRAP TO STOP THE PRAM/STROLLER ROLLING AWAY.
- ! ENSURE THAT ALL THE LOCKING DEVICES ARE ENGAGED BEFORE USE.
- ! DO NOT LET YOUR CHILD PLAY WITH THIS PRODUCT.
- ! CARRY COT IS ONLY SUITABLE FOR A CHILD WHO CANNOT SIT UP UNAIDED, ROLL OVER AND CANNOT PUSH ITSELF UP ON ITS HANDS AND KNEES. MAXIMUM WEIGHT OF THE CHILD: 9KG.
- ! DO NOT USE OR ADD ANY MATTRESS OTHER THAN THE ONE SUPPLIED WITH THE CARRY COT.
- ! NEVER LEAVE THE HARNESS BUCKLED WHEN NOT FITTED TO A CHILD IN THE PRAM/STROLLER BECAUSE THE HARNESS CAN FORM LOOPS WHICH MAY POSE A STRANGULATION HAZARD.
- ! THE USE OF ACCESSORIES NOT APPROVED BY THE VEHICLE MANUFACTURER IS UNSAFE.

- ! ADULT ASSEMBLY REQUIRED.
- ! THE MAXIMUM RECOMMENDED WEIGHT IN THE CUP-HOLDER IS 1LBS (0.5KG).
- ! USE THE STROLLER WITH A CHILD WEIGHING LESS THAN 22KG. IT WILL CAUSE DAMAGE TO THE STROLLER WITH AN UNFITTED CHILD.
- ! TO PREVENT A HAZARDOUS, UNSTABLE CONDITION, DO NOT PLACE MORE THAN 4.5KG IN THE STORAGE BASKET.
- ! THE PRAM/STROLLER IS NOT BE USED NEAR AN OPEN FIRE OR EXPOSED FLAME.
- ! USE THE PRAM/STROLLER WITH ONLY ONE CHILD AT A TIME. NEVER PLACE PURSES, SHOPPING BAGS, PARCELS OR ACCESSORY ITEMS ON THE HANDLE OR HOOD.
- ! OVERLOADING, FOLDING INCORRECTLY, OR USING COMPONENT PARTS FROM OTHER MANUFACTURERS MAY CAUSE THE PRAM/STROLLER TO BE DAMAGED, BROKEN OR UNSAFE. PLEASE READ THE INSTRUCTION MANUAL CAREFULLY.
- ! PLEASE READ ALL THE INSTRUCTIONS IN THE MANUAL BEFORE USING THE PRODUCT. PLEASE SAVE INSTRUCTION MANUAL FOR FUTURE USE. FAILURE TO FOLLOW THESE WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR DEATH.
- ! SAFETY BELTS AND RESTRAINT SYSTEMS MUST BE USED CORRECTLY.
- ! CHILD MAY SLIP INTO LEG OPENINGS AND BE STRANGLED IF THE HARNESS IS NOT USED.
- ! CARE SHOULD BE TAKEN IF THE PRAM/STROLLER IS USED ON STAIRS OR ESCALATORS.
- ! KEEP AWAY FROM HIGH TEMPERATURE OBJECTS, LIQUIDS, AND ELECTRONICS.
- ! NEVER ALLOW YOUR CHILD TO STAND ON THE PRAM/STROLLER OR SIT IN THE PRAM/STROLLER WITH HEAD TOWARD FRONT OF PRAM/STROLLER .

- ! NEVER PLACE THE PRAM/STROLLER ON ROADS, SLOPES OR DANGEROUS AREAS.
- ! DO MAKE SURE ALL MECHANISMS ARE FIXED BEFORE USING THE PRAM/STROLLER.
- ! TO AVOID STRANGULATION, DO NOT PLACE ITEMS WITH A STRING AROUND YOUR CHILD'S NECK, SUSPEND STRINGS FROM THIS PRODUCT, OR ATTACH STRINGS TO TOYS.
- ! DO NOT LIFT PRAM/STROLLER WHILE CHILD IS IN PRAM/STROLLER.
- ! DO NOT USE STORAGE BASKET AS A CHILD CARRIER.
- ! TO PREVENT TIPPING, NEVER LET CHILD CLIMB THE PRAM/STROLLER . ALWAYS LIFT THE CHILD IN AND OUT OF THE PRAM/STROLLER .
- ! TO AVOID FINGER ENTRAPMENT, USE CARE WHEN FOLDING AND UNFOLDING THE PRAM/STROLLER.
- ! PLEASE KEEP THE STORAGE LATCH LOCKING CORRECTLY WHEN LIFT AND MOVE THE UNIT. PLEASE TRANSPORT THE FOLDED STROLLER SAFELY.
- ! TO ENSURE YOUR CHILD'S SAFETY, PLEASE MAKE SURE ALL PARTS ARE ASSEMBLED AND FASTENED PROPERLY BEFORE USING THE PRAM/STROLLER.
- ! TO AVOID STRANGULATION, DO MAKE SURE YOUR CHILD IS CLEAR FROM THE CANOPY.
- ! THE VEHICLE IS DESIGNED FOR USE ON FLAT OR GENTLY SLOPING SURFACES AND MAY BE UNSTABLE ON HIGHER SLOPING AND UNEVEN SURFACES; RESULTING IN THE POSSIBILITY OF THE VEHICLE TIPPING OVER.
- ! DISCONTINUE USING PRAM/STROLLER IF IT IS DAMAGED OR BROKEN.
- ! THIS PRODUCT IS NOT SUITABLE FOR RUNNING OR SKATING. PRAM/STROLLER TO BE USED ONLY AT WALKING SPEED. THIS PRODUCT IS NOT INTENDED FOR USE WHILE JOGGING.

- ! TO AVOID SUFFOCATION, REMOVE PLASTIC BAG AND PACKAGING MATERIALS BEFORE USING THIS PRODUCT. THE PLASTIC BAG AND PACKAGING MATERIALS SHOULD THEN BE KEPT AWAY FROM BABIES AND CHILDREN.
- ! STROLLER DESIGNED TO BE USED FROM BIRTH SHALL RECOMMEND THE USE OF THE MOST RECLINED POSITION FOR NEW BORN BABIES.
- ! TO AVOID INJURY OR DEATH: ALWAYS APPLY THE BRAKES WHENEVER THE PRAM/STROLLER IS STATIONARY.
- ! EXTRA CARE IS NEEDED IF USED ON MOVING VEHICLES AND CHILD SHOULD NOT BE LEFT UNATTENDED, EVEN WITH BRAKES ENGAGED.
- ! USE THIS HARNESS AT ALL TIMES.
- ! SECURE THE CHILD IN THE HARNESS AT ALL TIMES.
- ! TO AVOID BURNS, NEVER PUT HOT LIQUIDS IN YOUR CUPHOLDER.
- ! FOR INFANT CHILD RESTRAINTS USED IN CONJUNCTION WITH A CHASSIS, THIS VEHICLE DOES NOT REPLACE A COT OR A BED. SHOULD YOUR CHILD NEED TO SLEEP, THEN IT SHOULD BE PLACED IN A SUITABLE PRAM BODY, COT OR BED.
- ! DO NOT ATTACH ITEMS TO THE HANDLE, SEAT BACK OR SIDES OF THE PRAM/STROLLER. ANY ADDITIONAL LOAD WILL AFFECT THE STABILITY OF THE PRAM/STROLLER AND COULD CAUSE THE PRAM/STROLLER TO TIP.
- ! WARNING TO AVOID SERIOUS INJURY, MAKE SURE THE CANOPY IS ASSEMBLED WHEN BACKREST IS IN THE MOST RECLINED POSITION.
- ! WARNING: DO NOT USE THIS BASSINET ONCE THE CHILD CAN SIT UP UNAIDED.
- ! WARNING: DO NOT USE FOR UNSUPERVISED SLEEPING.
- ! THE VEHICLE IS NOT TO BE USED AS AN UNSUPERVISED SLEEPING ENVIRONMENT.

## Stroller Assembly

(Please refer to figures on page 1-15)

Please read all the instructions in this manual before assembling and using this product.

### Open Stroller

see images ① - ④

Separate storage latch from storage mount ①, and then lift the handle upwards ②, a click sound means the stroller is open completely.

The seat is reversible. ④

! Check that the stroller is completely latched before continuing to use.

### Assemble & Detach Front Wheel

see images ⑤ - ⑥

### Assemble & Detach Rear Wheel

see images ⑦ - ⑧

### Assemble Canopy

see images ⑨ - ⑪

### Assemble & Detach Cupholder

see images ⑫ - ⑬

The completely assembled stroller is shown as ⑭

## Stroller Operation

### Adjust Backrest

see image ⑮

There are 4 recline angles for the backrest.

To raise or recline the backrest, rotate the recline handle on the back of the seat, pull down on the backrest. ⑮

! Please do not press the releasing button ⑮ - 3 on the middle of the recline handle when adjusting the angle for the recline.

! Make sure the recline is set properly for use.

! The maximum load of storage pocket on the back of backrest is 0.45kg.

### Use Buckle

see images ⑯ - ⑰

Release Buckle

Press the center button to release the buckle. ⑯

Lock Buckle

Match the waist belt buckle with the shoulder buckle ⑰ - 1, and click into the center buckle. ⑰ - 2 A “click” sound means the buckle is locked completely. ⑰ - 3

! To avoid serious injury from falling or sliding out, always secure your child with harness.

! Make sure your child is snugly secured. The space between the child and the shoulder harness is about the thickness of one hand.

! Do not cross the shoulder belts. This will cause pressure on a child’s neck.

## Use Shoulder & Waist Harnesses

see images 18 - 23

! In order to protect your child from falling out, after your child is placed into the seat, check whether the shoulder and waist harnesses are at proper height and length.

18 - 1 Shoulder harness anchor A

18 - 2 Shoulder harness anchor B

18 - 3 Slide adjuster

For larger child, use shoulder harness anchor A and the highest shoulder slots.

For smaller child, use shoulder harness anchor B and the lowest shoulder slots.

To adjust the position of the shoulder harness anchor, turn the anchor to be level with the side facing forward. Thread it through the shoulder harness slot from back to front. 21  
Rethread it through the slot that is closest to child's shoulder height. 22

Use slide adjuster to change the harness length. 23 - 1

Press the button 23 - 2, while pulling the waist harness to proper length. 23 - 3

## Use Armbar

see images 24 - 26

## Adjust Calf Support

see images 27 - 28

The calf support has 2 positions.

To lower calf support, press the adjustment buttons on both sides of the calf support 27 - 1, and rotate the calf support downwards. 27 - 2

To raise the calf support, push it upwards. A "click" sound means the calf is locked completely.

## Use Front Swivel Lock

see image 29

Rotate swivel lock left to orient, Rotate Swivel Lock right to release 29

**Tip** It is recommended to use swivel lock on uneven surfaces.

## Use Brake

see images 30 - 31

To lock wheels, step the brake lever downwards. 30

To release wheels, just lift the brake lever upwards. 31

**Tip** Always set the parking brake when stroller is not moving.

## Use Canopy

see images 32 - 34

The canopy can be opened completely to protect your child from the sun uttermostly, just unzip the zip 33, and then pull the canopy toward front.

## Adjust Handle

see image 35

## Switch Seat

see images 36 - 39

## Use Storage Bag

see image 40

The maximum load of each storage bag on the both side of basket is 0.45kg.

## Use Tether Strap

see image 41

Use the tether strap to prevent the stroller inadvertently rolling away.

## Fold Stroller

see images 42 - 53

- ! The button on the middle of the recline handle is used for folding the seat. 43 - 1
- ! The folded stroller can stand when the handle is in the lowest position. 47
- ! You can fold the stroller by pulling the webbing on the middle of the adapter when the adapter assembled on the frame. 52
- ! The storage latch will automatically hook onto the storage mount, then the stroller is folded and locked completely. 47 51 53
- ! You can lift the strap to transport the unit safely after folding the stroller. 48

## Use Accessories

Accessories may be sold separately or may not be available depending on region.

## Use with Infant Child Restraint

see images 54 - 60

When using with Joie infant child restraint Gemm & i-Gemm please refer to the following instructions.

- ! A “click” sound means the adapter is locked completely.
- ! The infant child restraint angle can be adjusted with our adjustable adaptors. 58
- ! If you have any problems about using the infant child restraint, please refer to their own instruction manuals.

! Please do not fold the stroller when the infant child restraint is still attached.

## Use Carry Cot

see images 61 - 64

When using with Joie ramble xl carry cot, please refer to the following instructions.

- ! A “click” sound means the adapter is locked completely.
- ! Always use the mattress when using the carry cot.
- ! If you have any problems about using the carry cot, please refer to their own instruction manuals.
- ! Please do not fold the stroller when the carry cot is still attached.

## Use Rain Cover

see image 65

To assemble the rain cover, place it over the seat.

- ! When using the rain cover, please always check its ventilation.
- ! When not in use, please check that the rain cover has been cleaned and dried before folding.
- ! Do not fold the stroller after assembling the rain cover.
- ! Do not place your child into the stroller assembled with rain cover during hot weather.

## Use Storage Pocket

see images 66 - 71

Total maximum weight of storage pocket must not exceed 1kg.

Storage Pocket can be removed from basket to use separately.

70

Use Insert  
see images 72 - 73

## Detach & Assemble Soft Goods

see images 74 - 76

To re-assemble seat soft goods, follow the steps above in reverse 76 - 74

## Cleaning and Maintenance

see image 77

- ! To clean stroller frame, use only household soap and warm water. No bleach or detergent. Please refer to the care label for instructions on cleaning the fabric parts of the stroller.
- ! All removable fabric parts may be washed in cold water and drip-dried. No bleach. Please refer to the care label for instructions on cleaning the fabric parts of the stroller.
- ! Any fabric parts which are not removable should be spot-cleaned using a soft cloth and warm soapy water.
- ! From time to time, check your stroller for loose screws, worn parts, torn material or stitching. Replace or repair the parts as needed. Periodically wipe clean plastic parts with a soft damp cloth. Always dry the metal parts to prevent the formation of rust if the stroller has come into contact with water.
- ! Excessive exposure to sun or heat could cause fading or warping of parts.
- ! If stroller becomes wet, open canopy and allow to dry thoroughly before storing.
- ! If wheels squeak, use a light oil (e.g., Silicon Spray, antirust oil, or sewing machine oil). It is important to get the oil into the axle and wheel assembly. 77
- ! When using your stroller at the beach or other sandy/dusty environments, completely clean your stroller after use to remove sand and salt from mechanisms and wheel assemblies.

NOTE



Allison Baby UK Ltd.  
Venture Point, Towers Business Park  
Rugeley, Staffordshire, WS15 1UZ

view all fine signature selections at  
[joiebaby.com/signature](http://joiebaby.com/signature)

IM-0006671